

Revision Date 2019-05-02

EN



# sonero



## USB-C Audio & Power Adapter

Adds audio in & out + Power Delivery to the USB-C port

X-UA210



...the ... of ...  
 ... the ... of ...  
 ... the ... of ...



## **DEAR CUSTOMER,**

thank you for purchasing this Item. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

## **INTRODUCTION**

The Type-C to Type-C PD and Headphone Jack Adapter is your ultimate mobile companion device, with USB-C Power Delivery (PD) charging and audio control support for accessibility on-the-go. Uncompromising on both style and performance, the Type-C Headphone Adapter delivers clear audio along with powerful charging, housed in a sleek enclosure. Simply connect the Type-C adapter to your USB-C smartphone, tablet or laptop for media control that travels with you.

## **INTENDED USE**

For safety and approval purposes (CE), you must not rebuild and/or modify this product. If you use the product for purposes other than those described above, the product may be damaged. In addition, improper use can cause hazards such as short circuiting, fire, electric shock etc.

Read the instructions carefully and keep them. Make this product available to third parties only together with its operating instructions.



## **INTENDED COUNTRIES**

Germany

Austria

## **SAFETY INSTRUCTIONS**

Read the operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling in this manual, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

The device is not a toy. Keep it out of the reach of children and pets.

Do not leave packaging material lying around carelessly. These may become dangerous playing material for children.

**Suffocation Risk!** Keep packaging materials away from children!

Protect the product from extreme temperatures, direct sunlight, strong jolts, high humidity, moisture, flammable gases, vapors and solvents.

Do not place the product under any mechanical stress.

If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental

use. Safe operation can no longer be guaranteed if the product:

- is visibly damaged,
- is visibly damaged,
- is no longer working properly,
- has been stored for an extended period in poor ambient conditions or
- has been subjected to any serious transport-related stresses.

Please handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

Also observe the safety and operating instructions of any other devices which are connected to the product.

Consult an expert when in doubt about the operation, safety or connection of the device.

To avoid damages to the sound system by inrush current, please switch the amplifier off before installing the product. Non-compliance may cause damages to power amplifier, sound system and your hearing! The amplifier is to be switched on last, after signal source and the product are already switched on.

## **DELIVERY CONTENTS**

- 1x USB Type C to CF (Audio) and CF (PD) Converter
- 1x User Manual DE / EN



## FEATURES

- Powerful PD Charging
- Modern, Ultra-Compact Design
- Restores Your Headphone Jack
- USB-C Compatibility
- Embedded 16bit audio DAC / ADC for Earphone, Phone and Microphone

## SPECIFICATIONS

### Compatible Devices:

2018 iPad Pro, 2018 MacBook Air, 2016/2017 MacBook Pro, 2016/2017 MacBook, Google Pixel 3/XL/2, Microsoft Surface Go, Samsung Galaxy S10/S9 Plus/S9, HTC U11/U12 and more.

Does not work with Moto and One Plus 6 devices.

### Connector Type

USB-C


### Dimensions & Weight

19 x 3 x 1cm, 12g

### Speed

Max power output: 89W

## CONNECTION DIAGRAM



1. Connect the Type-C Male connector to your laptop or smartphone.
2. Use your Type-C Audio Jack Headphone and plug it into the marked Type-C socket.
3. Use the USB-C charger and plug it into the USB Type-C socket to charge your mobile device.
4. You can charge and use your device simultaneously.



## **OPERATION**

Connect Type-C Headphone Jack Adapter to your compatible USB-C device.

Use the headphone jack port to connect 3.5mm auxiliary cables or headphones.

In-line volume control not supported

Use the USB-C PD port to fast charge your compatible device.

Unplugging charging cable will cause media to pause

Enjoy listening to movies or music while charging your USB-C device.

Audio will automatically be directed to the adapter even if there are no headphones connected

## **MAINTENANCE**

There are no components located inside the product that require maintenance. Never open or attempt to dismantle the product.

Maintenance, modifications and repairs are to be performed exclusively by an expert or at a qualified shop.

If you have questions which remain unanswered by these operating instructions, contact our technical support service or other technical personnel.



## **CLEANING**

Before cleaning the product, it must be disconnected from all other connected products.

Only use dry and soft cloth to clean the product housing of the.

Do not use abrasives or solvents.

Do not use any aggressive cleaning agents, rubbing alcohol or other chemical solutions as they can cause damage to the housing or cause malfunctions.

To clean the product, use a soft, dry cloth. Do not apply too much pressure to the housing as this may cause scratch marks.

You can easily remove dust using a soft bristled brush.

## **WARRANTY AND LIABILITY**

The manufacturer guarantees full statutory warranty terms on all new devices.

As the manufacturer has no influence on installation, warranty only applies to the product itself.

If any fault or damage is detected on your product, please contact your dealer and provide your sales slip or invoice as evidence of the purchase, if necessary. Your dealer will repair the fault either on site, or send the device to

the manufacturer. You make the work of our technicians considerably easier, describing possible faults in detail – only then can you be assured that intermittent faults, will be found and repaired with certainty!

The manufacturer is not liable for damages to persons or property caused by improper installation, operation or maintenance, not described in this manual.

Do not alter or modify the product or its accessories.

Any use other than described in this user`s manual is not permitted and causes loss of warranty, loss of guarantee, and non-liability.

## **CE CONFORMITY**

**CE** PureLink GmbH hereby declares that this product X-UA210 complies with Directives 2014/30/EU and 2014/35/EU.

The full text of the EU Declaration of Conformity is available at the following Internet address:  
[www.purelink.de](http://www.purelink.de)



## DISPOSAL OF THE DEVICE

WEEE-Reg. No.: DE 93 847 290



According to the European WEEE directive, any electrical and electronic equipment must not be disposed of along with consumer waste. As a consumer, you are committed by law to deposit electrical and electronic devices at public collecting points or to the dealer for free at the end of the device's lifetime. Details are regulated in the respective national legislations. The Wheelie Bin symbol on the product, in the manual or on the packaging refers to these terms. With the return of your used devices you actively take part in protecting the environment.

## DISCLAIMER

This product complies with the statutory national and European requirements. All company names and product names are trademarks of their respective owners.

All rights reserved.

We reserve our right for misprints and changes to the device, packaging or user manual.



sonero®  
PureLink GmbH  
Von-Liebig-Str. 10  
48432 Rheine  
Germany

Version 2.0  
Revision Date 2019-05-02